

*Congratulations on your purchase of marlanteak outdoor furniture. We trust it will provide you with many years of exceptional comfort and service. Take a few minutes to read through the relevant sections of this care instruction sheet to find out how you can maximise the lifespan of your investment and keep it looking great for generations to come.*

## CUSHIONS

Our cushions are not only comfortable but are made to last.

Tailored to fit each item of furniture perfectly, they feature removable covers made from durable 100% solution dyed all-weather acrylic fabric, which is both mould and mildew resistant.

All the ranges of outdoor fabric we use are Teflon-coated for maximum weather and stain resistance and are guaranteed against fading for 3 years.

The easiest way to keep your cushions clean is to wipe them down with a damp cloth on a regular basis. Cushions can be spot washed by sponging briskly with a solution of natural soap in lukewarm water. For stubborn stains or suntan lotion, use fabric spot remover.

Covers can be removed and machine washed at 40C, but **DO NOT TUMBLE DRY**. Iron at a low heat.

Before placing your cushions on your teak furniture for the first time, wipe your furniture down to prevent teak dust marking the cushions.

## GUARANTEES AND REPAIRS

All items from the Classic Teak range are guaranteed for five years, whereas all Kettal, Tribu, Gloster, Rausch and Roda furniture is guaranteed for two years against defects/manufacturing faults. Please keep your invoice for guarantee purposes.

We will happily repair or, if necessary, replace items under guarantee. Defective items need to be returned to our head office in Cape Town for the necessary repairs to be effected. All transport cost are the client's responsibility. Where items have been damaged due to misuse, negligence or other causes, such as wind damage, repairs will be charged for.